



In order to establish an advance setting, turn the gear counterclockwise. To establish a retard setting, turn the gear clockwise. In either case, do not turn the camshaft, turn only the gear.